Pairing Enzo to Receiver

Ensure your transmitter and receiver are paired. Check if your Enzo is in storage mode, indicated by a red LED that emits only when the button is being held. If your Enzo is **not** in storage mode, please see our **"Putting an Enzo in storage mode"** guide.

Turn your receiver on with the switch located on the left side.

Put your Enzo in pairing mode, hold the button for about 15 seconds, until it flashes with an **orange** light. You will see the Enzo go through 2 modes before reaching the pairing mode, first will be a **solid green** light, then a **green blinking** light.

Keep holding the button until you see the **orange** light, then release.

Hold the pair button on the receiver for 4 seconds until the LED on the front begins **blinking green**, quickly press the button on the Enzo.

The Enzo will rapidly blink several times and then stop.

This signifies you have successfully paired the Enzo.

POWERED BY: (((CareTech.

helpdesk@rtmcloud.com.au 1300 997 248 | rtmcloud.com.au





X C