


Storage Mode Enzo




1

Storage mode on an Enzo is indicated by an LED light that emits only when the button is pressed or held. You can use this mode for long term storage, or to reset the pairing of the Enzo.




2

Start by removing the screws on the back of the Enzo and pulling the case apart. Take the printed circuit board (PCB) out of the case.



3

Turn the PCB over to see the battery housing and slide the battery out.



4

Hold the button on the front of the PCB while sliding the battery back into the case. If this was done successfully, the LED should **flash red** only when the button is being held. If the LED flashes multiple times, you will need to reattempt this step.

5

Put the PCB back in the case, put the front of the case back on and close it up with the screws. Your Enzo is now in storage mode!